

WiFi Indicator Wireless Handheld User Manual









Searching J/Box S/No: 95009 The device during startup will show "searching for J/Box"

The serial number relates to the WiFi indicator that the handheld is paired with.





Once connected the wireless handheld will show the current Net and Gross Weight.

The menu system will allow you to scroll up or down: Scroll up through the menus

```
Up Arrow from Net Gross

Settings

Calibration

Engineering

Diagnostics

Back to Net / Gross
```

Down Arrow from Net Gross **Diagnostics**

```
Lagnostics

Engineering

Calibration

Settings

Back to Net Gross
```

Menu Descriptions

WiFi Weighing Indicator

Settings



Press Return to get to Contrast menu



Press Return - current settings will flash up





Up and Down arrow will increase or decrease the value.



Press Return to select value



Down Arrow takes you to the Back option




Press Return to return to the Settings menu



Menu Descriptions:

WiFi Weighing Indicator

Calibration - Tare







Press Return to scroll through each number

Press Return and the device will ask you to confirm the change



Press Return to confirm selection

Press Return on Back



Menu Descriptions

Calibration - Zero



Arrow Down from Tare menu



Press Return





Use Up and Down keys to select Y/No



Press Return to return to previous menu



Menu Descriptions:

Calibration - Span



Arrow Down from zero menu



Press Return

Span menu will show



Press Return and the number will

flash and become editable





WiFi Weighing Indicator





Use the Up and Down keys to change the value



Press Return to scroll through each number



Press Return and the device will ask you to confirm the change





Use the Up and Down keys to select Y/No



Press return to confirm selection



Press Return on back



Menu Descriptions

Engineering



Press Return

Will show current charge level



Down arrow will show Xpico setting (VWS Menu)



Down arrow - select Back



Press Return to return to previous menu





Menu Descriptions:

Diagnostics

- Press Return
 Will show battery status
 - Charging when on charge
 - No Input if on battery
- Down arrow will show Body Status Up/Down
- Down arrow Firmware version is displayed
- Down arrow serial number is displayed
- Down arrow J/Box serial number will show
- Down arrow select Back
- Press Return to return to previous menu

WiFi Weighing Indicator









